

LinHES - Support # 1019: Missing IR USB-UIRT transmitter and I would to add a TELUS transmitter codes

Status:	New	Priority:	Normal
Author:	paulpoco	Category:	Installation/Upgrade
Created:	11/05/2017	Assignee:	jams
Updated:	11/05/2017	Due date:	
Description:	<p>I am new to linHES.</p> <p>Had a previous system that had a working MythTV/Kodi using the USB-UIRT transmitter to change the channels of a TELUS stb.</p> <p>USB-UIRT is missing from remotes. Of I cannot find my old setup for this.</p> <p>TELUS is not in the list of boxes for transmitting. My uploaded file is general.conf.</p>		

History

11/05/2017 03:55 am - paulpoco

I forgot to mention I never did get the USB-UIRT to work in Linux along side the MCE receiver. I had to have a VM of Win 7 running Eventghost with a webpage of buttons to actually sent commands to actually press the buttons from Linux MythTV.